

ECM

COMPONENTS



ES



REMOVAL


1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

CAUTION:

Wait at least 90 seconds after disconnecting the cable from the negative (-) battery terminal to prevent airbag and seat belt pretensioner activation.


- 2. REMOVE AIR CLEANER CAP (See page ES-411)
- 3. REMOVE AIR CLEANER CASE
 - (a) Disconnect the harness clamp.
 - (b) Remove the 3 bolts and air cleaner case.





4. REMOVE ECM

(a) Remove the 3 bolts of the ECM with bracket.





(b) Disconnect the 2 ECM connectors.

NOTICE:

After disconnecting the connector, make sure that dirt, water and other foreign matter does not contact the connecting part of the connector.


- Raise the 2 levers while pushing the locks on the 2 levers, and disconnect the 2 ECM connectors.
- (c) Remove the ECM with bracket.






(d) Remove the 4 screws and 2 ECM brackets.





INSTALLATION

- 1. INSTALL ECM
 - (a) Install the 2 brackets to the ECM with the 4 screws. Torque: 3.0 N*m (30 kgf*cm, 27 in.*lbf)



(b) Connect the 2 ECM connectors.


NOTICE:

When connecting the connector, make sure that dirt, water and other foreign matter does not become stuck between the connector and other part.

(1) Connect the 2 ECM connectors and lower the 2 levers.

NOTICE:


Make sure that the 2 levers are securely lowered.



(c) Install the ECM with the 3 bolts.

Torque: 6.5 N*m (66 kgf*cm, 57 in.*lbf)

6.



2. INSTALL AIR CLEANER CASE

- (a) Install the air cleaner case with the 3 bolts. Torque: 5.0 N*m (51 kgf*cm, 44 in.*lbf)
- (b) Connect the harness clamp.
- 3. INSTALL AIR CLEANER CAP (See page ES-413)
- 4. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

5. PERFORM REGISTRATION

- (a) When replacing the ECM, the Vehicle Identification Number (VIN) must be input into the replacement ECM (see page ES-13).
- (b) When replacing the ECM, perform the vehicle stability control system recognition in the ECM (see page CC-12).

page CC-12). RESET MEMORY

(a) When replacing the ECM, perform the RESET MEMORY procedure (A/T initialization) (see page AX-18).

